

accessories

USB converter

USB Converter to RS-232 or RS-485



Description

- Converter of the USB network protocol to RS-232 or RS-485
- Power supply through the PC's USB port
- Transmission speed: 4800 bps to 128000 bps
- Recommended only for start-ups and possible communications

Application

To convert the USB signal to RS-232 or RS-485.

References

Type	Code
USB / RS-485 converter	M54040
USB / RS-232 converter	M54050

CVM-MINI Adaptor

Front panel adaptor



Description

Adaptor for the CVM-MINI for its installation on 72 x 72 mm panels

Application

- For 72 x 72 mm front panel
- Central fixing
- Adjustable on the rear with two straps

References

Type	Code
MINI panel adaptor	M5ZZF1