



## SWT96AN 75/5A 50kW

SWT96AN 75/5A 50kW, Scale

Code: M130LB.

- > System: Three-phase
- > Measurement Range (A): 75/5
- > Full scale: 50 kW
- > Device: WT96AN
- > Modules: 96x96

## Specifications

### Mechanical characteristics

|                                  |                  |
|----------------------------------|------------------|
| Size (mm) width x height x depth | 84 x 84 x 1 (mm) |
| Weight (kg)                      | 0,008            |

### SWM/SWT

Exchangeable scale for wattmeter WMC/WTC

| CODE    | TYPE                 | Measurement Range (A) | Modules | Device | Full scale |
|---------|----------------------|-----------------------|---------|--------|------------|
| M130J9. | SWM96 50/5A 20kW     | 50/5                  | 96x96   | WM96   | 20 kW      |
| M130JC. | SWM96 100/5A 40kW    | 100/5                 | 96x96   | WM96   | 40 kW      |
| M130JE. | SWM96 150/5A 60kW    | 150/5                 | 96x96   | WM96   | 60 kW      |
| M130JF. | SWM96 200/5A 80kW    | 200/5                 | 96x96   | WM96   | 80 kW      |
| M130JH. | SWM96 300/5A 120kW   | 300/5                 | 96x96   | WM96   | 120 kW     |
| M130JJ. | SWM96 400/5A 160kW   | 400/5                 | 96x96   | WM96   | 160 kW     |
| M130JK. | SWM96 500/5A 200kW   | 500/5                 | 96x96   | WM96   | 200 kW     |
| M130JL. | SWM96 600/5A 240kW   | 600/5                 | 96x96   | WM96   | 240 kW     |
| M130JP. | SWM96 1000/5A 400kW  | 1000/5                | 96x96   | WM96   | 400 kW     |
| M130JR. | SWM96 1500/5A 600kW  | 1500/5                | 96x96   | WM96   | 600 kW     |
| M130JS. | SWM96 2000/5A 800kW  | 2000/5                | 96x96   | WM96   | 800 kW     |
| M130JU. | SWM96 3000/5A 1,2MW  | 3000/5                | 96x96   | WM96   | 1,2 MW     |
| M130JV. | SWM96 4000/5A 1,6MW  | 4000/5                | 96x96   | WM96   | 1,6 MW     |
| M130JW. | SWM96 5000/5A 2MW    | 5000/5                | 96x96   | WM96   | 2 MW       |
| M130K9. | SWT96E 50/5A 30kW    | 50/5                  | 96x96   | WT96E  | 30 kW      |
| M130KB. | SWT96E 75/5A 50kW    | 75/5                  | 96x96   | WT96E  | 50 kW      |
| M130KC. | SWT96E 100/5A 60kW   | 100/5                 | 96x96   | WT96E  | 60 kW      |
| M130KE. | SWT96E 150/5A 90kW   | 150/5                 | 96x96   | WT96E  | 90 kW      |
| M130KF. | SWT96E 200/5A 120kW  | 200/5                 | 96x96   | WT96E  | 120 kW     |
| M130KH. | SWT96E 300/5A 180kW  | 300/5                 | 96x96   | WT96E  | 180 kW     |
| M130KJ. | SWT96E 400/5A 240kW  | 400/5                 | 96x96   | WT96E  | 240 kW     |
| M130KK. | SWT96E 500/5A 300kW  | 500/5                 | 96x96   | WT96E  | 300 kW     |
| M130KL. | SWT96E 600/5A 360kW  | 600/5                 | 96x96   | WT96E  | 360 kW     |
| M130KP. | SWT96E 1000/5A 600kW | 1000/5                | 96x96   | WT96E  | 600 kW     |



## SWT96AN 75/5A 50kW

Code: M130LB.

| CODE    | TYPE                  | Measurement Range (A) | Modules | Device | Full scale |
|---------|-----------------------|-----------------------|---------|--------|------------|
| M130KR. | SWT96E 1500/5A 900kW  | 1500/5                | 96x96   | WT96E  | 900 kW     |
| M130KS. | SWT96E 2000/5A 1,2MW  | 2000/5                | 96x96   | WT96E  | 1,2 MW     |
| M130KU. | SWT96E 3000/5A 1,8MW  | 3000/5                | 96x96   | WT96E  | 1,8 MW     |
| M130KV. | SWT96E 4000/5A 2,4MW  | 4000/5                | 96x96   | WT96E  | 2,4 MW     |
| M130KW. | SWT96E 5000/5A 3MW    | 5000/5                | 96x96   | WT96E  | 3 MW       |
| M130L9. | SWT96AN 50/5A 30kW    | 50/5                  | 96x96   | WT96AN | 30 kW      |
| M130LB. | SWT96AN 75/5A 50kW    | 75/5                  | 96x96   | WT96AN | 50 kW      |
| M130LC. | SWT96AN 100/5A 60kW   | 100/5                 | 96x96   | WT96AN | 60 kW      |
| M130LE. | SWT96AN 150/5A 90kW   | 150/5                 | 96x96   | WT96AN | 90 kW      |
| M130LF. | SWT96AN 200/5A 120kW  | 200/5                 | 96x96   | WT96AN | 120 kW     |
| M130LH. | SWT96AN 300/5A 180kW  | 300/5                 | 96x96   | WT96AN | 180 kW     |
| M130LJ. | SWT96AN 400/5A 240kW  | 400/5                 | 96x96   | WT96AN | 240 kW     |
| M130LK. | SWT96AN 500/5A 300kW  | 500/5                 | 96x96   | WT96AN | 300 kW     |
| M130LL. | SWT96AN 600/5A 360kW  | 600/5                 | 96x96   | WT96AN | 360 kW     |
| M130LP. | SWT96AN 1000/5A 600kW | 1000/5                | 96x96   | WT96AN | 600 kW     |
| M130LR. | SWT96AN 1500/5A 900kW | 1500/5                | 96x96   | WT96AN | 900 kW     |
| M130LS. | SWT96AN 2000/5A 1,2MW | 2000/5                | 96x96   | WT96AN | 1.2 MW     |
| M130LU. | SWT96AN 3000/5A 1,8MW | 3000/5                | 96x96   | WT96AN | 1.8 MW     |
| M130LV. | SWT96AN 4000/5A 2,4MW | 4000/5                | 96x96   | WT96AN | 2,4 MW     |
| M130LW. | SWT96AN 5000/5A 3MW   | 5000/5                | 96x96   | WT96AN | 3 MW       |