



FEMC144 100/√3 V

FEMC144 100 /√3 V, Phasemeter

Code: M13441. DESCATALOGADO

> Scale: 90° P1

> System: Single-phase

> Accuracy: 1,5

> Measurement Range (V): 100 /√3

> Modules: 144x144

Description

- O Does not need an auxiliary power supply
- $\circ~$ DIN box with dimensions 96 and 144 mm
- o Class 1.5
- o Built-in electronic converter
- o Balanced single and three-phase circuits

Application

Measurement of $\mbox{cos}\phi$ in balanced or unbalanced single and three-phase circuits.







FEMC144 100/√3 V

Phasemeters

Code: M13441.

Specifications

Mechanical characteristics	
Size (mm) width x height x depth	144 x 144 x 71.8 (mm)
Fastening	Panel
Weight (kg)	0,69
Environmental characteristics	
Protection class	Panel: IP 52 (Front), IP 00 (Terminals)
Storage temperature	-25+40 °C
Working temperature	+10 +30 °C
Standards	
Certifications	CE
Electrical safety, Maximum height (m)	2000
Standards	BS 89, UNE-EN 60051, IEC 144, DIN 43780, IEC 51, UNE 21318
Current measurement circuit	
Consumption	1,5 VA
Sampling frequency	20 100 Hz
Nominal current (In)	5 A
Allowable overload	1,2 In permanent / 5 In during 30s / 10 In during 5s / 40 In during 1s
Voltage measurement circuit	
Consumption	1 VA
Sampling frequency	40 70 Hz
Maximum permanent measurement voltage	1,2 Vn permanent rated voltage / 2 Vn during 5s
Electrical characteristics	
Insulation voltage, circuit	2 kV, 50 Hz, 1 min entre mecanismo y caja
Measurement accuracy	
Accuracy	± 1,5 % FE

FEMC / FETC

Single phase and three-phase 90° electronic phase-meters

CODE	TYPE	Scale	Accuracy	Modules		
Single-phase						
M13434.	FEMC96 110V	90° P1	1,5	96x96		







FEMC144 100 / √3 V

Phasemeters

Code: M13441.

CODE	TYPE	Scale	Accuracy	Modules			
Balanced three-phase							
M1343F.	FETC96 400V	90° P1	1,5	96x96			

Current range: 0.1 to 1.2 In. For the connection of transformers .../5A. Built-in electronic transducer.







FEMC144 100 /√3 V

Phasemeters

Code: M13441.

Dimensions Connections



