



## USB-RS 485

---

USB-RS 485, USB to RS-485,

Code: M54040. **DESCATALOGADO**

### Description

---

- Converter of the USB network protocol to RS-232 or RS-485
- Power supply through the PC's USB port
- Transmission speed: 4800 bps to 128000 bps
- Recommended only for start-ups and possible communications

### Application

---

To convert the USB signal to RS-232 or RS-485.



# USB-RS 485

USB converter to RS-232 or RS-485

Code: M54040.

## Specifications

### Environmental characteristics

Relative humidity (without condensation)	10 ... 90 %
Storage temperature	-10 ... +55 °C
Working temperature	0 ... +55 °C

### Mechanical characteristics

Weight (kg)	0,027
-------------	-------

### USB-RS

USB to RS-485 / RS-232 Converter

CODE	TYPE	Description
USB		
D80320.	USB-RS 485	USB to RS-485 Converter