



## USB-RS 485

---

USB-RS 485, USB to RS-485,

Code: M54040.

### Description

---

- Converter of the USB network protocol to RS-232 or RS-485
- Power supply through the PC's USB port
- Transmission speed: 4800 bps to 128000 bps
- Recommended only for start-ups and possible communications

### Application

---

To convert the USB signal to RS-232 or RS-485.



## USB-RS 485

USB converter to RS-232 or RS-485

Code: M54040.

### Specifications

#### Environmental characteristics

|  |                |
|--|----------------|
| Relative humidity (without condensation) | 10 ... 90 %    |
| Storage temperature                      | -10 ... +55 °C |
| Working temperature                      | 0 ... +55 °C   |

#### Mechanical characteristics

|             |       |
|-------------|-------|
| Weight (kg) | 0,027 |
|-------------|-------|

#### USB-RS

USB to RS-485 / RS-232 Converter

| CODE    | TYPE       | Description             |
|---------|------------|-------------------------|
| USB     |            |                         |
| M54040. | USB-RS 485 | USB to RS-485 Converter |
| M54050. | USB-RS 232 | USB to RS-232 Converter |