



WTC96E 400V .../5A

WTC96 400V .../5A, Valtmeter

Code: M13032.

> Scale: 90° P1

> System: Balanced three-phase

> Accuracy: 1,5

> Measure: 400 Vph-ph, .../5 A

> Device: WTC96 > Modules: 96x96

Description

- O Does not need an auxiliary power supply
- O DIN box with dimensions 96 and 144.
- o Class 1.5
- o Built-in electronic converter
- o Balanced and unbalanced single and three-phase circuits.

Application

Measurement of active power in balanced or unbalanced single and three-phase circuits.







WTC96E 400V .../5A

Wattmeters and varmeters

Code: M13032.

Specifications

Mechanical characteristics		
Size (mm) width x height x depth	96 x 96 x 49.2 (mm)	
Fastening	Panel	
Weight (kg)	0,29	

WMC / WTC

Single-phase and three-phase wattmeters

CODE	TYPE	Scale	Accuracy	Modules	Device	Measure
Single-pha	se					
M13031.	WMC96 400V/5A	90° P1	1,5	96x96	WMC96	400 Vph-ph,/5 A
M13041.	WMC144 400V/5A	90° P1	1,5	96x96	WMC144	400 Vph-ph,/5 A
Balanced th	hree-phase					
M13032.	WTC96E 400V/5A	90° P1	1,5	96x96	WTC96	400 Vph-ph,/5 A
Three-phas	se 3 wire (ARON)					
M13034.	WTC96A 110V/5A	90° P1	1,5	96x96	WTC96A	110 Vph-ph,/5A
Three-phas	se 4 wire					
M13033.	WTC96AN 400V/5A	90° P1	1,5	96x96	WTC96AN	400 Vph-ph,/5 A

Exchangeable scales for types WMC 96, WTC 96E and WTC 96AN. Scale not included (*1) Specify primary voltage and current of the measuring transformers, and power at full scale







WTC96E 400V .../5A

Wattmeters and varmeters

Code: M13032.

Dimensions

Connections



