



### **PIC96E 110 V**

PIC96E 110 V, Phasemeter

Code: M13637. (CONSULTAR DISPONIBILIDAD)

> Scale: 360°, P1

> System: Unbalanced three-phase

> Accuracy: 1,5

> Measurement Range (V): 110

> Modules: 96x96

#### Description

- O Does not need an auxiliary power supply
- $\circ~$  DIN box with dimensions 96 and 144.
- o Class 1.5
- o Balanced and unbalanced single and three-phase circuits.
- o 4 quadrants

#### **Application**

Measurement of  $\mbox{cos}\phi$  in balanced or unbalanced single and three-phase circuits.







## **PIC96E 110 V**

Phasemeters

Code: M13637.

### **Specifications**

| 96 x 96 x 101.2 (mm)   |
|--|
| Panel  |
| 1,41   |
|  |
| Panel: IP 52 (Front), IP 00 (Terminals)  |
| -25+40 °C  |
| +10 +30 °C   |
|  |
| CE, UL   |
| 2000   |
| BS 89, UNE-EN 60051, IEC 144, UL 94, DIN 43780, IEC 51, UNE 21318                                  |
|  |
| 2,5 VA   |
| 20 100 Hz  |
|  |
| 5 A  |
| 5 A<br>1,2 In permanent / 5 In during 30s / 10 In during 5s / 40 In during 1s                      |
|  |
|  |
| 1,2 In permanent / 5 In during 30s / 10 In during 5s / 40 In during 1s                             |
| 1,2 In permanent / 5 In during 30s / 10 In during 5s / 40 In during 1s  15 mA                      |
| 1,2 In permanent / 5 In during 30s / 10 In during 5s / 40 In during 1s  15 mA                      |
| 1,2 In permanent / 5 In during 30s / 10 In during 5s / 40 In during 1s  15 mA  45 55 Hz / 54 66 Hz |
|  |

Current range: 0.1 to 1.2 In. For the connection of transformers .../5A.









## **PIC96E 110 V**

Phasemeters

Code: M13637.

# **Dimensions**

Connections





