



## **PIC144E 110V**

PIC144E 110V, Phasemeter

Code: M13647. DESCATALOGADO

> Scale: 360°, P1

> System: Unbalanced three-phase

> Accuracy: 1,5

> Measurement Range (V): 110

> Modules: 144x144

### Description

- O Does not need an auxiliary power supply
- $\circ~$  DIN box with dimensions 96 and 144.
- o Class 1.5
- o Balanced and unbalanced single and three-phase circuits.
- o 4 quadrants

### **Application**

Measurement of  $\mbox{cos}\phi$  in balanced or unbalanced single and three-phase circuits.







# **PIC144E 110V**

Phasemeters

Code: M13647.

## **Specifications**

144 x 144 x 102 (mm)
Panel
1,46
Panel: IP 52 (Front), IP 00 (Terminals)
-25+40 °C
+10 +30 °C
CE, UL
2000
BS 89, UNE-EN 60051, IEC 144, UL 94, DIN 43780, IEC 51, UNE 21318
2,5 VA
20 100 Hz
20 100 112
5 A
5 A
5 A
5 A  1,2 In permanent / 5 In during 30s / 10 In during 5s / 40 In during 1s
5 A  1,2 In permanent / 5 In during 30s / 10 In during 5s / 40 In during 1s  15 mA
5 A  1,2 In permanent / 5 In during 30s / 10 In during 5s / 40 In during 1s  15 mA
5 A  1,2 In permanent / 5 In during 30s / 10 In during 5s / 40 In during 1s  15 mA  45 55 Hz / 54 66 Hz

Current range: 0.1 to 1.2 In. For the connection of transformers .../5A.







# **PIC144E 110V**

Phasemeters

Code: M13647.

#### Connections Dimensions



