



### 410-QT5A-B0B10

410-QT5A-B0B10, Three-phase energy meter indirect connection

Code: QB8I0

> Type Consumer: 3

> Discon. relay: No > Communications: RS-232 | PRIME

> N° relays: 0

> Class (Active/Reactive): B (1) / 2

> System: Three-phase

> Measure: Indirect > Measurement Range (V): 3x230/400

> Measurement Range (A): .../5

> Quadrants: 4

> Frequency (Hz): 50

#### **Specifications**

Size (mm) width x height x depth	172 x 255 x 67 (mm)	
Envelope	DIN 43859	
Weight (kg)	0,95	
Environmental characteristics		
Relative humidity (without condensation)	95 % max.	
Storage temperature	-40 +85 °C	
Working temperature	-40 +70 °C	
Current measurement circuit		
Consumption	< 0,1 VA	
Reference current (Iref)	5 A	
Maximum current	10 A	
Minimum current measurement	< 0,2 x ltr	
Communication Network		
Technology / Type	PRIME	
Optical communication interface		
Hardware	IEC 62056-21	
Protocol	DLMS	
Туре	Serial;bi-directional	
User interface		
Resolution of the display	up to 8 digits (8 mm)	
Display type	LCD	



PLC





### 410-QT5A-B0B10

Three-phase energy meter indirect connection

Code: QB8I0

Hardware	CENELEC
Protocol	DLMS / PRIME
Modulation system	OFDM
Measurement accuracy	
Reactive energy measurement (kvarh)	IEC 62053-23 (Class 2)
Active energy measurement (kWh)	EN 50470 (Class B) IEC 62053-21 (Class 1)
Features / performance	
Billing closures	12 locks per contract. Programable date and hour
Load curve	1 load curves, programmable integration time (1 60 min)
Tariff programming	12 days 24 types of data 6 types of tariffs 30 public holidays
Clock	
Source	Temperature compensated oscillator
Accuracy (EN 61038)	< 0,5 s/day (23 °C)

Gregorian calendar

RS-232

#### Technology / Type

Serial communication

Туре

# **CIRWATT B 410TP**Three-phase energy meters indirect connection

Туре Discon. Measurement Class CODE TYPE Quadrants Communications N° relays Measure (Active/Reactive) Consumer relay Range (A) CIRWATT B 410TP, indirect connection QB8I0 410-QT5A-B0B10 3 RS-232 | PRIME Indirect .../5 B (1) / 2







# 410-QT5A-B0B10

Three-phase energy meter indirect connection

Code: QB8I0

# **Dimensions**

# Connections





